

How to Rebuild an Original Model Kneepad

*** Please refer to Diagram for steps 3-5**

1. Take all parts off ONE kneepad. (Keep the other kneepad together to use as a reference guide!)
2. Scrape off as much of the old adhesive as possible – Do NOT use any solvents on frame.
3. Install **Knee Seat Cushion** - Take backing paper off to reveal the adhesive and then push into place, aligning edge of cushion where knee seat meets shin plate.
4. Install **Shin Plate Cushion** by steps below:
 - 4a - Place **Rivet** through the **Washer** and then put front of **Rivet** through top side of **Shin Plate Cushion**.
 - 4b - Put **Barrel Post** through **Shin Plate Hole** from bottom of frame.
 - Insert **Rivet** into **Barrel Post** as far as you can and use rivet gun to push **Rivet** into **Barrel Post**.
 - Then pop **Rivet** with rivet gun.
5. If **Shin Plate Cushion** is too long, cut Cushion so it fits flush to the already installed **Knee Seat Cushion**. Then remove backing paper to reveal adhesive and push into place.
6. Snap new boots and liners into place.
7. If you need to replace Quick Release Buckles – remove old rivet and washer and install new.
8. Repeat steps 1-7 for the second leg.

